



Badge application guide

You will need:-

- **your school badge**
- **your garment**
- **an iron**
- **a sheet of kitchen paper**
- **a flat and sturdy work surface**

First select your work surface. A low table is ideal as it allows you to exert maximum pressure as you press.

Set your iron to its highest heat setting and allow it to warm-up for a couple of minutes. If you have a steam iron make sure the tank is empty.

Lay the garment flat and position the badge. We suggest you follow the guidelines at the bottom of this sheet. You may need to make a slight adjustment for some styles and sizes. Before you start pressing make sure the badge is level!

Cover the badge with the kitchen paper. Place the middle of the iron over the badge and press as firmly as possible for 60 seconds. Do not move the iron as you press. Turn the garment inside out and repeat for a further 60 seconds. This allows the special adhesive to melt thoroughly to create a strong bond between the badge and the garment.

Finally check that you are happy with the finish, paying particular attention to the edges. You may need to repeat the second part of the pressing process with thicker fleece fabrics.

Once you have finished pressing allow the garment to cool. It takes 24 hours for the bond to reach its maximum strength.

Wash the garment according to the care label and iron as normal. Ironing the logo will improve the bond between the badge and the fabric.

